



Classic 3', 4', & 5' Assembly Instructions

Thank you for purchasing a Classic storage box from Cape May Box Co. We have a simple method to assist you with your box assembly utilizing the alphabet. Each screw hole of the Classic has been lettered. There are three different sized screws provided for box assembly. All you need is a screwdriver. The screws included in the assembly are as follows:

3' Classic Indoor or Outdoor Box

- 16 • 1 $\frac{1}{4}$ " screws for the bottom of the box
- 16 • 1 $\frac{5}{8}$ " screws for the side panels and trim
- 6 • #8 brass screws for the pre-drilled and hinged lid

4' Classic Indoor or Outdoor Box

- 16 • 1 $\frac{1}{4}$ " screws for the bottom of the box
- 16 • 1 $\frac{5}{8}$ " screws for the side panels and trim
- 9 • #8 brass screws for the pre-drilled and hinged lid

5' Classic Outdoor Box

- 16 • 1 $\frac{1}{4}$ " screws for the bottom panel of the box
- 24 • 1 $\frac{5}{8}$ " screws for the side panels and trim
- 12 • #8 brass screws for the pre-drilled and hinged lid

1. Begin by assembling the side panels of the box with the 1 $\frac{5}{8}$ " screws. Screw the panels together and the moldings.
2. Place the bottom panel in place. Using the 1 $\frac{1}{4}$ " screws, install the bottom panel.
3. Finally, place the lid on top of the box and line the pre-drilled holes up with the lid's hinge. Using the #8 brass screws fasten the hinge to the box.

If you have any problems with assembling your box please call us at 856-455-1212 or 1-877-262-3327. We would be happy to talk you through the assembly process.



Classic 3', 4', & 5' Assembly Instructions

Thank you for purchasing a Classic storage box from Cape May Box Co. We have a simple method to assist you with your box assembly utilizing the alphabet. Each screw hole of the Classic has been lettered. There are three different sized screws provided for box assembly. All you need is a screwdriver. The screws included in the assembly are as follows:

3' Classic Indoor or Outdoor Box

- 16 • 1 $\frac{1}{4}$ " screws for the bottom of the box
- 16 • 1 $\frac{5}{8}$ " screws for the side panels and trim
- 6 • #8 brass screws for the pre-drilled and hinged lid

4' Classic Indoor or Outdoor Box

- 16 • 1 $\frac{1}{4}$ " screws for the bottom of the box
- 16 • 1 $\frac{5}{8}$ " screws for the side panels and trim
- 9 • #8 brass screws for the pre-drilled and hinged lid

5' Classic Outdoor Box

- 16 • 1 $\frac{1}{4}$ " screws for the bottom panel of the box
- 24 • 1 $\frac{5}{8}$ " screws for the side panels and trim
- 12 • #8 brass screws for the pre-drilled and hinged lid

1. Begin by assembling the side panels of the box with the 1 $\frac{5}{8}$ " screws. Screw the panels together and the moldings.
2. Place the bottom panel in place. Using the 1 $\frac{1}{4}$ " screws, install the bottom panel.
3. Finally, place the lid on top of the box and line the pre-drilled holes up with the lid's hinge. Using the #8 brass screws fasten the hinge to the box.

If you have any problems with assembling your box please call us at 856-455-1212 or 1-877-262-3327. We would be happy to talk you through the assembly process.